

How and where install an ACC TAG device

Important: When installing the device, please follow the instructions carefully. If inappropriate methods or place for installation are used, the device may either fall or will not be registered when passing through the toll booth.

INSTALLATION INFORMATION

1. POSITION (passenger cars)

On the inside of the windshield, at least 5 cm from the top of the windshield and behind the mirror in order to be out of the driver's sight.

2. CLEANING

Before installing the holder, please clean the intended installation site with the tissue. Using any other means or tissues except for the intended one may result in poor adhesion to the surface and the device may fall off.

3. INSTALLATION

Stick the device holder on the prepared and cleaned windshield surface and then put the device itself. Please avoid contact with the sticky part of the holder in order to avoid damaging the bonding quality.